



HDL-MR0416D.431

4CH 16A High Power Switch Actuator (with Dry Contact) HDL-MR0816D.432

8CH 16A High Power Switch Actuator (with Dry Contact) HDL-MR1216D.433

12CH 16A High Power Switch Actuator (with Dry Contact)

Issued: May 6, 2021 File Edition: V1.0.2





Figure 1. 4CH 16A High Power Switch Actuator (with Dry Contact)

(with Dry Contact)



Figure 3. 12CH 16A High Power Switch Actuato (with Dry Contact)




Figure 4. HDL-MR0416D.431

Figure 5. HDL-MR0816D.432




Figure 6. HDL-MR1216D.433



Figure 4-7. Dimensions

#### Overview

4(8/12)CH 16A High Power Switch Actuator (with Dry Contact) (See Figure 1-3) has 4/8/12 channels(16A for each channel) and 50A magnetic latching relay. With low power consumption and long lifetime, the module has manual control switches and supports scene and sequence control.

#### **Functions**

- 4/8/12-channel relay output unit
- 3/4/4 dry contact channels
- Scene control and sequence control
- Up to 4/8/12 separate zones
- Up to 13 scenes for each zone, and 12 of which are available for editing, scene running time up to 60 minutes
- 2 sequences for each zone, up to 12 steps for each sequence
- Light protection delay for each channel (0-60 minutes)
- Mass turn-on delay for each channel (0-25 seconds)
- Manual switch for each channel
- Stair lamp function of the channel settable
- Selected scene or scene before power off automatically activated when device restarts
- HDL Buspro communication
- Supports online upgrade

### **Important Notes**

- Buspro cable CAT5E or dedicated HDL Buspro cable
- Buspro connection Series connection (hand-in-hand recommended).
- Maximum current for each output channel: 16A
- One 16A breaker for each channel for protection

#### **Product Information**

Dimensions - See Figure 4 - 7 Wiring - See Figure 8

- 1. Connect to load
- 2. Bypass switch
- 3. Programming button & module indicator

Indicator flashes when device is in normal working mode. Press the button for 3 seconds, then the ID can be read and modified via HDL Buspro Setup Tool.


## Safety Precautions (1)



- The installation and testing for the product must be carried out by HDL Automation Co., Ltd. or its appointed service agencies. The electric construction shall comply with local laws and safety regulations.
- The device should be installed with DIN rail in DB box. HDL will not be responsible for any consequence caused by the inexpert or faulty installation and wiring methods, which are not in accordance with the instructions contained in this operating instruction.
- Please do not privately disassemble or replace any parts of the product. Otherwise, it may cause mechanical fault, electric shock, fire or personal injuries.
- Please contact our after-sales departments or our designated service agencies for your maintenance service. Product failures caused by private disassembly are not subject to this warranty.
- It is not allowed to exceed the range.


#### Package Contents

4(8/12)CH 16A High Power Switch Actuator (with Dry Contact) \*1 / Buspro connector\*1 / Label\*5 / Datasheet\*1



Take the connection of HDL-MR0416D.431 as an example Figure 8. Wiring








Figure 9. Installation

Technical support

E-mail: hdltickets@hdlautomation.com Website: https://www.hdlautomation.com

©Copyright by HDL Automation Co., Ltd. All rights reserved. Specifications subject to change without notice.

### **Technical Data**

Basic Parameters		
Working voltage	24~30V DC	
Working current	40mA/24V DC	
Input voltage	120V/240V AC (50/60Hz)	
Output channel	HDL-MR0416D.431: 4CH, 16A/CH HDL-MR0816D.432: 8CH, 16A/CH HDL-MR1216D.433: 12CH, 16A/CH	
Pry contact input	HDL-MR0416D.431: 3CH HDL-MR0816D.432: 4CH HDL-MR1216D.433: 4CH	
elay	50A Magnetic latching relay	
aximum current output of each channel	16A	
lectronic life time of relay	>60000 (Resistive load)	
rotection	Connect a breaker to each channel	
xternal Environment		
orking temperature	-5°C~45°C	
orking relative humidity	≤90%	
orage temperature	-20°C~60°C	
orage relative humidity	≤93%	
pecifications		
nensions	HDL-MR0416D.431: 72mm×90mm×64mm HDL-MR0816D.432: 144mm×90mm×64mm HDL-MR1216D.433: 216mm×90mm×64mm	
t weight	HDL-MR0416D.431: 264g HDL-MR0816D.432: 487g HDL-MR1216D.433: 722g	
ousing material	Nylon, PC	
stallation	35mm DIN rail installation (See Figure 9)	
rotection rating (Compliant with EN 60529)	IP20	
ecommended Load Types and Power		
0V, 16A, Resistive, 100,000 cycles, 40°C;		
10V, 16FLA/96LRA, Motor, 30,000 cycles, 40°C;		
40V, 16A, Standard Ballast, 30,000 cycles, 40°C;		
IOV, 16A, Electronic Ballast, 6,000 cycles, 40°C;		

240V, 16A, Electronic Ballast, 6,000 cycles, 40°C;

120V, 16FLA/96LRA, Motor, 30,000 cycles,  $40^{\circ}\text{C};$ 

120V, 16A, Electronic Ballast, 6,000 cycles, 40°C;

120V, 16A, Standard Ballast, 30,000 cycles,  $40^{\circ}\text{C};$ 

### **Approved**

CE

RoHS

# **HDL Buspro Cable Guide**

HDL Buspro	HDL Buspro Cable	CAT5/CAT5E
DATA+	Yellow	Blue/Green
DATA-	White	Blue white/Green white
СОМ	Black	Brown white/Orange white
24V DC	Red	Brown/Orange

#### Installation

### Installation - See Figure 9 (Take HDL-MR0416D.431 as an example)

- Step 1. Fix the DIN rail with screws.
- Step 2. Buckle the bottom cap of the actuator on the edge of the DIN rail.
- Step 3. Press the device on the DIN rail, slide it and fix it up until an appropriate position is adjusted.